



ChrismaColor™ Painted Glass Guide to Adhesives

Mounting Surface Preparation:

ChrismaColor™ Painted Glass can be affixed to many different type of surfaces. The key to preparing the mounting surface is make sure the surface is clean, dry, smooth, level and verifying the surface can support the weight of the glass panel(s). The installer should review and be familiar with the adhesive manufacturer's instructions for use. Apply the adhesive according to the adhesive manufacturer's instructions.

Adhesives:

National Glass Products has tested Bohle's XtraGrip and found it to be compatible with the coatings used to manufacture ChrismaColor Painted Glass. The installer should follow the adhesive manufacturer written instructions. National Glass Products advises using a mechanical fastener in addition to with adhesive to support the weight of the glass panel(s) and to secure the glass while the adhesive cures.